



2002-2006 Toyota Camry Oil And Oil Filter Replacement

A video tutorial on how to replace and change out the oil and oil filter on a 2002-2006 Toyota Camry.

Written By: eCuration



INTRODUCTION

This short video guide will show you how to replace the oil and oil filter on your 2002-2006 Toyota Camry.

Do this maintenance every 5k miles.

[video: <https://www.youtube.com/watch?v=Zj3tlcGqjU8>]



TOOLS:

- [Hydraulic Floor Jack](#) (1)
- [Jack Stand](#) (1)
- [3/8" Drive Ratchet](#) (1)
- [10" Ratchet Extension](#) (1)
- [14 mm socket](#) (1)
- [Oil Drain Pan](#) (1)
- [Oil Filter Wrench](#) (1)
- [Long Neck Funnel](#) (1)



PARTS:

- [5W-30 Motor Oil](#) (5)
- [Oil Filter Engine Toyota Camry 2002-2006](#) (1)

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-10-04 05:14:45 PM.